



Caution when connecting an external footswitch

You must power-off the unit before connecting an external footswitch. If you connect the footswitch while the power is on, **recorded data might be lost.**

Changing how the LOOP indicator operates (display mode) during overdubbing and playback

1. While holding down the pedal switch, turn the power on (insert a plug into the OUTPUT A jack).
The LOOP indicator (red) lights, indicating the current recording mode.
2. Press the pedal switch twice (leaving at least one second between presses).
The LOOP indicator (red and green) lights, indicating the current display mode.

Display mode		Explanation
Red and green	 Upper half	The rotational speed of the LOOP indicator changes according to the length of the recorded phrase (default setting).
	 Lower half	The LOOP indicator rotates rapidly; then the playback location blinks.

3. Press the pedal switch successively twice (within one second) to change the display mode.
4. When the power is turned off and on again, the unit returns to normal operation.



外部フットスイッチを接続するときのご注意

必ず本機の電源を切った状態で、外部フットスイッチを接続してください。

電源を入れたまま接続すると、録音したデータが失われることがあります。



オーバーダビング／再生中の LOOP インジケータの動作（表示モード）を変更する

1. ペダル・スイッチを押しながら電源をオンにします（OUTPUT A 端子にプラグを差し込みます）。

LOOP インジケータ（赤）が点灯し、現在の録音モードが表示されます。

2. ペダル・スイッチを 2 回（1 秒以上の間隔で）押します。

LOOP インジケータ（赤と緑）が点灯し、現在の表示モードが表示されます。

表示モード		説明
赤と緑	 上半分	録音されたフレーズの長さに応じて、LOOP インジケータの回転スピードが変わります（初期値）。
	 下半分	LOOP インジケータが素早く回転したあと、再生位置が点滅表示されます。

3. ペダル・スイッチを 2 回連続（1 秒以内）で押して、表示モードを変更します。
4. 電源を入れ直すと通常状態に戻ります。